

# **BAXI S.p.A.**



## **SPARE PARTS CATALOGUE**

**- JULY 2007 -**



# HOW TO READ THE SPARE PARTS CATALOGUE

In the spare part catalogue, after the exploded diagrams, there are the components lists of the boilers; this is the meaning of the different columns:

Pos.	Identification number of the component in the exploded diagram of the boiler.
Description	Short description of the component.
Code	BAXI S.p.A. code of the component.
Tab. XX	XX is the exploded diagram number of the boiler taken into consideration.
From serial number	Date (year and week) identifying the beginning of production of a component (taken from the serial number of the boiler). e.g. B005: year 2000 (B identifies the decade 2000-2009; 0 identifies the year) – 5th week. If the box is empty, the component is in use from the beginning of production of the boiler.
To serial number	Date (year and week) identifying the end of production of a component (taken from the serial number of the boiler). e.g. B012: year 2000 (B identifies the decade 2000-2009; 0 identifies the year) – 12th week. If the box is empty, the component is still in use.
Interchangeable	It identifies the interchangeability between the new component and the old one. YES: components are interchangeable. NO: components are not interchangeable.

**BOILERS CONNECTION BOARD - EXPLODED VIEW**  
**TABELLA COLLEGAMENTO CODICE CALDAIA - ESPLOSO**  
**TABLERO UNIÓN CALDERA - EXPLOSIONADO**  
**TABLEAU CONNECTION CODEX CHAUDIERE - VUE ECLATEE**

<b>BOILER CODE</b>	<b>BOILER DESCRIPTION</b>	<b>EXPLODED REF.</b>
<b>CODICE CALDAIA</b>	<b>DESCRIZIONE CALDAIA</b>	<b>RIF. ESPLOSO</b>
<b>CODIGO CALDERA</b>	<b>DESCRIPCION CALDERA</b>	<b>REF. EXPLOSIONADO</b>
<b>CODE CHAUDIÈRE</b>	<b>DESCRIPTION CHAUDIÈRE</b>	<b>RÉF. EXPLOSÉE</b>
HLB435123001	PRIME HT 1.120	Tab 133
HLB435123002	PRIME HT 1.120	Tab 134
HLB435123003	PRIME HT 1.120	Tab 135
HLB435123004	PRIME HT 1.120	Tab 135
HLB435243001	PRIME HT 1.240	Tab 133
HLB435243002	PRIME HT 1.240	Tab 134
HLB435243003	PRIME HT 1.240	Tab 135
HLB435243004	PRIME HT 1.240	Tab 135
HLB436243000	PRIME HT 240	Tab 128
HLB436243001	PRIME HT 240	Tab 130
HLB436243002	PRIME HT 240	Tab 132
HLB436283001	PRIME HT 280	Tab 128
HLB436283002	PRIME HT 280	Tab 130
HLB436283003	PRIME HT 280	Tab 132
HLB436333001	PRIME HT 330	Tab 128
HLB436333002	PRIME HT 330	Tab 130
HLB436333003	PRIME HT 330	Tab 132
HSE437243000	PRIME STORAGE HT 240	Tab 129
HSE437243001	PRIME STORAGE HT 240	Tab 129



HSE437243001  
PRIME STORAGE HT 240  
HSE437243000  
PRIME STORAGE HT 240  
HLB436333003  
PRIME HT 330  
HLB436333002  
PRIME HT 330  
HLB436333001  
PRIME HT 330  
HLB436283003  
PRIME HT 280  
HLB436283002  
PRIME HT 280  
HLB436283001  
PRIME HT 280  
HLB436243002  
PRIME HT 240  
HLB436243001  
PRIME HT 240  
HLB436243000  
PRIME HT 240  
HLB435243004  
PRIME HT 1.240  
HLB435243003  
PRIME HT 1.240  
HLB435243002  
PRIME HT 1.240  
HLB435123002  
PRIME HT 1.120  
HLB435123001  
PRIME HT 1.120

Pos	Code	Description code																								To serial number	From serial number	Intercha ngeable:		
1	5106510	REAR SUPPORT																								B640				
1	5116480	SUPPORT FRAME																										B641		
2	5113450	PANEL ASSEMBLY - LEFT	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	B640				
2	5116220	LEFT PANEL HT	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		B641			
2	5663160	LEFT PANEL ASSEMBLY																								B640				
2	5684630	LEFT PANEL ASSEMBLY SX ATM																									B641			
3	5113440	PANEL ASSEMBLY - RIGHT	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	B640				
3	5116210	RIGHT PANEL HT	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		B641			
3	5663140	RIGHT PANEL ASSEMBLY FF																									B640			
3	5684620	RIGHT PANEL ASSEMBLY FF																										B641		
4	5114530	PANEL FRONT	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	B640				
4	5115330	FRONTAL PANEL NUVOLA HT																									B640			
4	5116350	FRONTAL PANEL ECO3	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		B641			
4	5116470	FRONTAL PANEL																										B641		
5	5114030	UPPER BAR NUVOLA HT330																												
6	5106550	VALVE SUPPORT RAIL																												
7	5107950	OUTERCASE BRACKET																												
8	5408080	PRESSURE SWITCH PIPE L=270	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•					
8	5410080	SILICONE PIPE D.8 L=800																												
10	5409020	FLUE ADAPTOR HE	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•					
10	5409990	FLUE CONNECTION 60/100																												
11	5409010	GASKET ADAPTOR	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•					
12	5108690	PLATE BLANKING	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•					
13	5407400	SUCTION CAP GASKET	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•					
18	5663330	PRESSURE SENSING VENTURI																												
18	5663490	PRESSURE SENSING VENTURI																												
18	5664290	PRESSURE SENSING VENTURI																												
18	5664300	VENTURI ASSEMBLY .12	•	•	•	•		•	•	•	•	•	•	•	•															
21	5402050	WASHER-SEALING	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•					

**PRIME**

Pos	Code	Description code	HLB435123001 PRIME HT 1.120	HLB435123002 PRIME HT 1.120	HLB435123003 PRIME HT 1.120	HLB435123004 PRIME HT 1.120	HLB435243001 PRIME HT 1.240	HLB435243002 PRIME HT 1.240	HLB435243003 PRIME HT 1.240	HLB435243004 PRIME HT 1.240	HLB436243000 PRIME HT 240	HLB436243001 PRIME HT 240	HLB436243002 PRIME HT 240	HLB436243003 PRIME HT 240	HLB436243004 PRIME HT 240	HLB436283001 PRIME HT 280	HLB436283002 PRIME HT 280	HLB436283003 PRIME HT 280	HLB436283004 PRIME HT 280	HLB436333002 PRIME HT 330	HLB436333003 PRIME HT 330	HSE437243000 PRIME STORAGE HT 240	HSE437243001 PRIME STORAGE HT 240	To serial number	From serial number	Intercha ngeable:	
22	5662680	FAN	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	B624		YES	
22	5682500	FAN	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	B642	B625	YES	
22	5686970	FAN	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		B643		
26	5114000	LEFT SIDE PANEL SEALED CHAMBER																					•	•			
27	5114510	COMBUSTION CHAMBER ACCUMUL HT																					•	•	B645		
27	5114820	COMBUSTION CHAMBER ASSY	•			•					•					•					•				B536		
27	5115740	SEALED CHAMBER REAR PANEL	•			•					•					•					•					B537	NO
27	5115880	SEALED CHAMBER REAR PANEL		•			•					•									•						
27	5116330	COMBUSTION CHAMBER ACCUMUL HT																					•	•		B646	YES
27	5116590	SEALED CHAMBER REAR PANEL				•	•					•										•					
29	5410450	REAR INSULATION																					•	•			
29	5412010	CERAMIC PANEL BASIC	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•					
30	5409100	CERAMIC PANEL																					•	•			
30	5411020	INSULATION PANEL	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•					
32	5663510	CONDENSING EXCHANGER 5E																					•	•			
32	5671940	HEAT EXCHANGER BASIC 4E	•	•	•	•					•	•	•														
32	5671950	HEAT EXCHANGER					•	•	•	•			•	•	•												
32	5671960	HEAT EXCHANGER																			•	•	•				
33	5403130	O-RING 22 x 3	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
34	5113650	PRIMARY EXCHANGER FIXING CLIP																					•	•			
34	8380860	FIXING CLIP	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•					
35	5629130	EXPANSION VESSEL 7,5 L.																					•	•			
35	5662620	EXPANSION VESSEL 8L	•	•	•	•	•	•	•	•	•	•	•	•	•												
35	5662630	EXPANSION VESSEL 10 L																			•	•	•				
37	5666790	FRONTAL ASS. C.S. NUVOLA HT																					•	•	B726		
37	5672080	COMBUSTION CHAMBER FRONT	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			B718		
37	5689640	COMB CHAMBER FRONTAL PANEL	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				B719	YES
37	5689680	FRONTAL PANEL ASS NUVOLA HT																					•	•		B727	YES
38	5401610	VIEWING WINDOW GASKET	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			



# PRIME

Pos	Code	Description code	HLB435123001 PRIME HT 1.120	HLB435123002 PRIME HT 1.120	HLB435123003 PRIME HT 1.120	HLB435123004 PRIME HT 1.120	HLB435243001 PRIME HT 1.240	HLB435243002 PRIME HT 1.240	HLB435243003 PRIME HT 1.240	HLB435243004 PRIME HT 1.240	HLB436243001 PRIME HT 240	HLB436243002 PRIME HT 240	HLB436243003 PRIME HT 280	HLB436243004 PRIME HT 280	HLB436333001 PRIME HT 330	HLB436333002 PRIME HT 330	HLB436333003 PRIME HT 330	HSE437243000 PRIME STORAGE HT 240	HSE437243001 PRIME STORAGE HT 240	To serial number	From serial number	Intercha ngeable:	
80	5666600	SANITARY INLET CONNECTOR ASS.																	•	•			
80	5671530	HALL SENS. GROUP 8L WITH TAP									•	•	•	•	•								
80	5671540	DHW INLET/HEAT.RET.HALL EF/TAP													•	•	•						
81	617060	FILTER RESTRICTOR GROUP 8L									•	•	•	•									
81	617140	FILTER RESTRICTOR 10L													•	•	•						
83	5620090	FLOW RATE LIMITATOR - 12 L/MIN																	•	•			
83	5666110	RESTRICTOR									•	•	•	•									
83	5666120	FLOW RESTRICTOR													•	•	•						
87	5210710	PUMP CONNECTING ELEMENT									•	•	•	•	•	•	•						
90	611930	FILLING GROUP									•	•	•	•	•	•	•						
90	5622840	FILLING TAP MM G 3/8																	•	•			
91	5652030	DRAINING TAP	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
92	9950600	SAFETY VALVE 3 BAR																	•	•			
92	9951170	SAFETY VALVE 3 BAR	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•						
95	5668740	TAP/ANODE ASSEMBLY																	•	•			
96	5668550	COIL PIPE ASS./HR PUMP																	•	•			
98	5212040	PIPE (HEATING SYSTEM-BY PASS)																	•	•			
98	5212890	BY PASS PIPE ASSY									•	•	•	•	•	•	•						
98	5672770	BY-PASS PIPE ASSEMBLY	•	•	•	•	•	•	•	•													
99	8380850	FIXING CLIP	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•						
102	5663040	3 PORT VALVE ASSEMBLY																	•	•			
102	5671520	V3V GROUP -15.0431-									•	•	•	•	•	•	•						
102	5672730	3 WAY VALVE ASSEMBLY	•	•	•	•	•	•	•	•													
104	5668570	SANITARY OUTLET PIPE																	•	•			
109	5207810	GASKET 10 X 14 X 1.5																	•	•			
112	5405320	DIAPHRAGM PRESSOSTAT																	•	•			
113	617100	BY-PASS GR.	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•						
114	400200	O-RING 25,07X2,62																	•	•			
119	605760	HYDRAULIC VENTURI ASSEMBLY	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•						





Pos	Code	Description code	HLB435123001 PRIME HT 1.120	HLB435123002 PRIME HT 1.120	HLB435123003 PRIME HT 1.120	HLB435123004 PRIME HT 1.120	HLB435243001 PRIME HT 1.240	HLB435243002 PRIME HT 1.240	HLB435243003 PRIME HT 1.240	HLB435243004 PRIME HT 1.240	HLB436243000 PRIME HT 240	HLB436243001 PRIME HT 240	HLB436243002 PRIME HT 280	HLB436283001 PRIME HT 280	HLB436283002 PRIME HT 280	HLB436283003 PRIME HT 330	HLB436333001 PRIME HT 330	HLB436333002 PRIME HT 330	HLB436333003 PRIME HT 330	HSE437243001 PRIME STORAGE HT 240	HSE437243002 PRIME STORAGE HT 240	HSE437243003 PRIME STORAGE HT 240	To serial number	From serial number	Intercha ngeable:	
120	600750	SPACER ASSEMBLY	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•						
122	5405370	O-RING									•	•	•	•	•	•	•	•	•	•						
131	8434840	NTC SENSOR	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	B615		YES	
131	8435400	NTC SENSOR	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		B616		
132	5402830	WASHER - SENSOR SEALING	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
134	5212120	INJECTOR	•	•	•	•																				
134	5212140	INJECTOR					•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
134	5212150	INJECTOR															•	•	•	•	•	•				
135	9950760	THERMOSTAT - LIMIT	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
136	5666520	EXCHANGER/3 PORT VALVE PIPE --																			•	•				
136	5672050	PIPE	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
136	5672060	PIPE-H/EXCHANGER															•	•	•	•	•	•				
138	5402010	O RING 22.22x2.62	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
139	5206620	CONNECTOR-GAS VALVE INLET	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
139	5637870	VALVE FEED PIPE																			•	•				
140	5671930	GAS VALVE	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
147	5109720	LOWER PANEL.OUTERCASE																			•	•		B640		
147	5116500	LOWER PANEL OUTERCASE																			•	•			B641	
147	5662810	MOUNTING PANEL-HYDRAULICS									•	•	•	•	•	•	•	•	•	•	•	•				
147	5664340	TRAVERSE	•	•	•	•	•	•	•	•																
151	5407650	ELECTRICAL BOX COVER	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
152	5671880	CONTROL PANEL PRIME HT 330															•	•	•	•	•	•				
152	5671900	CONTROL PANEL HT 280											•	•	•											
152	5672110	PRINT.CONTR.PAN.PRIME HT 1.240					•	•	•	•																
152	5672120	PRINT.CONTR.PAN.PRIME HT 1.120	•	•	•	•																				
152	5678420	PRNTD CNTRL PAN PRIME STOR HT																			•	•				
152	5680600	PRNTD CNTRL PAN PRIME HT 240										•	•	•												
153	5407660	PANEL - ACCESS	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
154	5676120	PCB SIEMENS LMU34 WITH INSTRUC	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•		B540		YES



Pos	Code	Description code	HSE437243001 PRIME STORAGE HT 240 HSE437243000 PRIME STORAGE HT 240 HL B436333003 PRIME HT 330 HL B436333002 PRIME HT 330 HL B436333001 PRIME HT 330 HL B436283003 PRIME HT 280 HL B436283002 PRIME HT 280 HL B436283001 PRIME HT 280 HL B436243002 PRIME HT 240 HL B436243001 PRIME HT 240 HL B436243000 PRIME HT 240 HL B435243004 PRIME HT 1.240 HL B435243003 PRIME HT 1.240 HL B435243002 PRIME HT 1.240 HL B435243001 PRIME HT 1.240 HL B435123004 PRIME HT 1.120 HL B435123003 PRIME HT 1.120 HL B435123002 PRIME HT 1.120 HL B435123001 PRIME HT 1.120																To serial number	From serial number	Interchangeable:		
			154	5680240	PCB LMU 34 SIEMENS	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	B620
154	5684110	PCB LMU 34 B	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	B635	B621	YES
154	5686050	GR.SCHEDA LMU 34 B C/ISTRUZ.	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•			B636	
154	5686070	PCB LMU34 PRIME STORAGE																				B636	
165	5668580	SANITARY INLET PIPE ASSEMBLY																					
166	8421590	TERMINAL BLOCK	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
167	5405340	FUSE HOLDER	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
168	9950580	FUSE	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
169	5656220	PRESSURE GAUGE WITH SUPPORT																					
169	9951020	GAUGE PRESSURE	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
174	5410530	KNOB SELECTOR SWITCH	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
190	5404970	WASHER - SEALING G3/8	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
191	5404640	SEALING WASHER G 1/2	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
191	5408970	WASHER - SEALING G1/2																					
192	5404650	SEALING WASHER G 3/4	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
200	5646560	HYDRAULIC CONNECTION SET																					
200	5658440	HYDRAULIC CONNECTIONS BLUE -A-																					
200	5660970	CONNECTION ASSEMBLY	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
201	5626860	HEATING CONNECTION																					
204	5625980	CONNECT.SANITARY AND INLET TAP																					
204	5626840	DHW INLET TAP																					
204	5636230	DHW INLET TAP	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
207	5625230	DHW OUTLET GROUP																					
209	5626850	GAS TAP GROUP																					
209	5627620	CONNECTION GAS INLET TAP	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
210	9950830	GAS TAP	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
212	5408330	BICONIC GASKET	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
216	5626790	FILLING TAP																					
218	5658460	HEATING FLOW TAP WITH FILTER	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				






**PRIME**


Pos	Code	Description code	HLB435123001 PRIME HT 1.120	HLB435123002 PRIME HT 1.120	HLB435123003 PRIME HT 1.120	HLB435123004 PRIME HT 1.240	HLB435243001 PRIME HT 1.240	HLB435243002 PRIME HT 1.240	HLB435243003 PRIME HT 1.240	HLB436243001 PRIME HT 240	HLB436243002 PRIME HT 240	HLB436283001 PRIME HT 280	HLB436283003 PRIME HT 280	HLB436333002 PRIME HT 330	HLB436333001 PRIME HT 330	HSE437243000 PRIME STORAGE HT 240	HSE437243001 PRIME STORAGE HT 240	To serial number	From serial number	Intercha ngeable:	
491	5637070	PLUG WITH FILTER ASSEMBLY								●	●	●	●	●	●						
493	612130	FILLING KNOB ASSEMBLY								●	●	●	●	●	●						
496	400020	O-RING	●	●	●	●	●	●	●	●	●	●	●	●	●						
498	400030	O-RING								●	●	●	●	●	●						
510	600760	DHW PADDLE ASSEMBLY	●	●	●	●	●	●	●	●	●	●	●	●	●						
511	5404600	O.R. 17,86x2,62	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●				
514	5663010	PUMP FILTER CONNEC. ASS.														●	●				
516	5210670	STUD-FRONT PANEL	●	●	●	●	●	●	●	●	●	●	●	●	●						
518	5107180	PIN-HINGED FACIA PANEL 28/28I	●	●	●	●	●	●	●	●	●	●	●	●	●						
525	8435260	IGNITOR	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●				
600	5112530	SPRING								●	●	●	●	●	●						
601	5408560	O-RING 8,73x1,78	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●			
607	8434930	CONTACT SENSOR														●	●				
621	5663120	FILLING PIPE D.8														●	●				
624	8435280	SENSOR HALL EFFECT								●	●	●	●	●	●						
631	5663310	AIR VENT PIPE ASSEMBLY														●	●				
631	5685240	AIR VENT PIPE - E125			●	●			●	●			●			●					
636	5658380	HEATING FLOW TAP WITHOUT FILTR								●	●	●	●	●	●						
636	5660980	HEATING FLOW TAP WITH FILTER	●	●	●	●	●	●	●												
637	5658470	HEATING FLOW TAP WITHOUT FILTR								●	●	●	●	●	●						
637	5660650	TAP	●	●	●	●	●	●	●												
647	5652730	AUTO AIR VENT			●	●			●	●			●			●	●	●			
671	5646780	DRAINING TAP G 1/2 (COPPER)														●	●				
672	5668560	PIPE														●	●				
673	5410030	PIPE EPDM 15X23 L=280														●	●				
673	5412190	PIPE CONNECTION SYPHO		●	●	●		●	●	●	●		●	●							
674	5409410	GASKET EXCHANGER 5/6 E														●	●				
675	8380780	FIXING SPRING FOR EXCHANGER														●	●				
677	5212000	5 ELEMENTS CABLE														●	●				

# PRIME

Pos	Code	Description code	HLB435123001 PRIME HT 1.120	HLB435123002 PRIME HT 1.120	HLB435123003 PRIME HT 1.120	HLB435123004 PRIME HT 1.120	HLB435243001 PRIME HT 1.240	HLB435243002 PRIME HT 1.240	HLB435243003 PRIME HT 1.240	HLB435243004 PRIME HT 1.240	HLB436243000 PRIME HT 240	HLB436243001 PRIME HT 240	HLB436243002 PRIME HT 240	HLB436283001 PRIME HT 280	HLB436283003 PRIME HT 280	HLB436283002 PRIME HT 280	HLB436333001 PRIME HT 330	HLB436333002 PRIME HT 330	HLB436333003 PRIME HT 330	HSE437243001 PRIME STORAGE HT 240	HSE437243000 PRIME STORAGE HT 240	To serial number	From serial number	Intercha ngeable:		
677	5212920	EXTENTION 4 EL.	•	•	•	•					•	•	•													
677	5212930	EXTENSION					•	•	•	•				•	•	•										
678	5665130	AIR/GAS COVER ASSEMBLY																			•	•				
678	5672130	AIR/GAS COVER ASSY	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•						
679	8511150	EARTH/IGNITOR CABLE	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
680	5409250	GROMMET-PIPE ASSY. D.15	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
681	5409120	PROTECTION CAP-ELECTRODE	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
682	5211800	SIGHT GLASS	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
686	5663020	BY-PASS PLUG ASSEMBLY	•	•	•	•	•	•	•	•											•	•				
707	5410960	REDUCER DIAM.80/60	•			•					•			•			•									
708	5410970	GASKET WITH DOUBLE LIP	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
709	8423160	TERMINAL BLOCK	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
710	5411030	GASKET	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•					
738	620490	ASS.GR./ORING/SPRING 12.0059	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•					
999	8414620	POWER CABLE	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•				
999	8418860	PLUG - PCB	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•					
999	8511330	DHW PRIORITY/ SENSOR WIRING	•	•	•	•	•	•	•	•																
999	8511610	WIRING HARNESS	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•					


# Tab 128














# Tab 133



# Tab 134



# Tab 135



**BAXI**

**BAXI S.p.A.**  
**Via Trozzetti, 20**  
**36061 BASSANO DEL GRAPPA (VI)**  
**ITALY**  
**Tel. +390424517111**  
**Telefax +390424517379**  
**E-mail. [service@baxi.it](mailto:service@baxi.it)**